

Video Issues

I get sound, but my Video is black.

- 🔗 You might not be using a supported capture card. Please check our System Requirements page at www.sagetv.com/requirements.html.
- 🔗 Go to the display settings for your video card. You more than likely have the Overlay surface set to be on the monitor only, so video will show up as black on your TV.
- 🔗 Make sure you have a Video Decoder installed and selected in your Detailed Setup -> Video. Try a different Video Decoder. Also try uninstalling SageTV and deleting the Frey Technologies folder. Reinstall SageTV. In V2 or later, you can also try disabling Overlay Color Keying.